

gputils 0.13.7

James Bowman, Craig Franklin, and David Barnett

November 20, 2007

Contents

1	Introduction	3
1.1	Tool Flows	3
1.1.1	Absolute Asm Mode	3
1.1.2	Relocatable Asm Mode	3
1.1.3	Which Tool Flow is best?	4
1.2	Supported processors	4
2	gpasm	7
2.1	Running gpasm	7
2.1.1	Using gpasm with “make”	8
2.1.2	Dealing with errors	9
2.2	Syntax	9
2.2.1	File structure	9
2.2.2	Expressions	9
2.2.3	Numbers	11
2.2.4	Preprocessor	12
2.2.5	Processor header files	12
2.3	Directives	13
2.3.1	Code generation	13
2.3.2	Configuration	13
2.3.3	Conditional assembly	13
2.3.4	Macros	13
2.3.5	\$	14
2.3.6	Suggestions for structuring your code	14
2.3.7	Directive summary	15
2.3.8	High level extensions	25
2.4	Instructions	28
2.4.1	Instruction set summary	29
2.5	Errors/Warnings/Messages	31
2.5.1	Errors	32
2.5.2	Warnings	35
2.5.3	Messages	36

3	gplink	38
3.1	Running gplink	38
3.2	gplink outputs	39
3.3	Linker scripts	39
3.4	Stacks	39
3.5	Optimization	39
3.5.1	Level 0	39
3.5.2	Level 1 (default)	39
3.5.3	Level 2	39
3.5.4	Level 3	40
4	gplib	41
4.1	Running gplib	41
4.2	Creating an archive	41
4.3	Other gplib operations	42
4.4	Archive format	42
5	Utilities	43
5.1	gpdasm	43
5.1.1	Running gpdasm	43
5.1.2	Comments on Disassembling	44
5.2	gpstrip	44
5.2.1	Running gpstrip	44
5.3	gpvc	44
5.3.1	Running gpvc	45
5.4	gpvo	45
5.4.1	Running gpvo	45

Chapter 1

Introduction

gputils is a collection of tools for Microchip (TM) PIC microcontrollers. It includes gpasm, gplink, and gplib. Each tool is intended to be an open source replacement for a corresponding Microchip (TM) tool. This manual covers the basics of running the tools. For more details on a microcontroller, consult the manual for the specific PICmicro product that you are using.

This document is part of gputils.

gputils is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2, or (at your option) any later version.

gputils is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with gputils; see the file COPYING. If not, write to the Free Software Foundation, 59 Temple Place - Suite 330, Boston, MA 02111-1307, USA.

1.1 Tool Flows

gputils can be used in two different ways: absolute asm mode and relocatable asm mode.

1.1.1 Absolute Asm Mode

In absolute asm mode, an assembly language source file is directly converted into a hex file by gpasm. This method is absolute because the final addresses are hard coded into the source file.

1.1.2 Relocatable Asm Mode

In relocatable asm mode, the microcontroller assembly source code is divided into separate modules. Each module is assembled into an object using gpasm. That object can be placed “anywhere” in microcontroller’s memory. Then gplink is used to resolve symbols references, assign final address, and to patch the machine code with the final addresses. The output from gplink is an absolute executable object.

1.1.3 Which Tool Flow is best?

Absolute mode is simple to understand and to use. It only requires one tool, `gpasm`. Most of the examples on Microchip's website use absolute mode. So why use relocatable mode?

- Code can be written without regard to addresses. This makes it easier to write and reuse.
- The objects can be archived to create a library, which also simplifies reuse.
- Recompiling a project can be faster, because you only compile the portions that have changed.
- Files can have local name spaces. The user chooses what symbols are global.

Most development tools use relocatable objects for these reasons. The few that don't are generally micro-controller tools. Their applications are so small that absolute mode isn't impractical. For PICs, relocatable mode has one big disadvantage. The bank and page control is a challenge.

1.2 Supported processors

`gputils` currently supports all processors supported by MPLAB 8.20 (except `eeeprom16` and related devices). This includes the following processors:

<code>eeeprom8</code>	<code>gen</code>	<code>hcs1365</code>	<code>hcs1370</code>	<code>mcv08a</code>	<code>mcv14a</code>
<code>mcv18a</code>	<code>mcv28a</code>	<code>p10f200</code>	<code>p10f202</code>	<code>p10f204</code>	<code>p10f206</code>
<code>p10f220</code>	<code>p10f222</code>	<code>p12c508</code>	<code>p12c508a</code>	<code>p12f508</code>	<code>p12c509</code>
<code>p12c509a</code>	<code>p12cr509a</code>	<code>p12f509</code>	<code>p12f510</code>	<code>p12ce518</code>	<code>p12ce519</code>
<code>p12f519</code>	<code>p12f609</code>	<code>p12hv609</code>	<code>p12f615</code>	<code>p12hv615</code>	<code>p12f629</code>
<code>p12f635</code>	<code>p12c671</code>	<code>p12c672</code>	<code>p12ce673</code>	<code>p12ce674</code>	<code>p12f675</code>
<code>p12f683</code>	<code>p14000</code>	<code>p16cxx</code>	<code>p16f1933</code>	<code>p16lf1933</code>	<code>p16f1934</code>
<code>p16lf1934</code>	<code>p16f1936</code>	<code>p16lf1936</code>	<code>p16f1937</code>	<code>p16lf1937</code>	<code>p16c432</code>
<code>p16c433</code>	<code>p16c5x</code>	<code>p16c505</code>	<code>p16f505</code>	<code>p16f506</code>	<code>p16c52</code>
<code>p16f526</code>	<code>p16c54</code>	<code>p16c54a</code>	<code>p16c54b</code>	<code>p16c54c</code>	<code>p16cr54</code>
<code>p16cr54a</code>	<code>p16cr54b</code>	<code>p16cr54c</code>	<code>p16f54</code>	<code>p16hv540</code>	<code>p16c55</code>
<code>p16c55a</code>	<code>p16c554</code>	<code>p16c557</code>	<code>p16c558</code>	<code>p16c56</code>	<code>p16c56a</code>
<code>p16cr56a</code>	<code>p16c57</code>	<code>p16c57c</code>	<code>p16cr57a</code>	<code>p16cr57b</code>	<code>p16cr57c</code>
<code>p16f57</code>	<code>p16c58a</code>	<code>p16c58b</code>	<code>p16cr58a</code>	<code>p16cr58b</code>	<code>p16f59</code>
<code>p16c61</code>	<code>p16f610</code>	<code>p16hv610</code>	<code>p16f616</code>	<code>p16hv616</code>	<code>p16c62</code>
<code>p16c62a</code>	<code>p16c62b</code>	<code>p16cr62</code>	<code>p16c620</code>	<code>p16c620a</code>	<code>p16cr620a</code>
<code>p16c621</code>	<code>p16c621a</code>	<code>p16c622</code>	<code>p16c622a</code>	<code>p16ce623</code>	<code>p16ce624</code>
<code>p16ce625</code>	<code>p16f627</code>	<code>p16f627a</code>	<code>p16f628</code>	<code>p16f628a</code>	<code>p16c63</code>
<code>p16c63a</code>	<code>p16cr63</code>	<code>p16f630</code>	<code>p16f631</code>	<code>p16f636</code>	<code>p16f639</code>
<code>p16c64</code>	<code>p16c64a</code>	<code>p16cr64</code>	<code>p16c642</code>	<code>p16f648a</code>	<code>p16c65</code>
<code>p16c65a</code>	<code>p16c65b</code>	<code>p16cr65</code>	<code>p16c66</code>	<code>p16c662</code>	<code>p16c67</code>
<code>p16f676</code>	<code>p16f677</code>	<code>p16f684</code>	<code>p16f685</code>	<code>p16f687</code>	<code>p16f688</code>
<code>p16f689</code>	<code>p16f690</code>	<code>p16c71</code>	<code>p16c710</code>	<code>p16c711</code>	<code>p16c712</code>
<code>p16c715</code>	<code>p16c716</code>	<code>p16f716</code>	<code>p16c717</code>	<code>p16c72</code>	<code>p16c72a</code>
<code>p16cr72</code>	<code>p16f72</code>	<code>p16f722</code>	<code>p16lf722</code>	<code>p16f723</code>	<code>p16lf723</code>

p16f724	p16lf724	p16f726	p16lf726	p16f727	p16lf727
p16c73	p16c73a	p16c73b	p16f73	p16f737	p16c74
p16c74a	p16c74b	p16f74	p16c745	p16f747	p16c76
p16f76	p16c765	p16f767	p16c77	p16f77	p16c770
p16c771	p16c773	p16c774	p16f777	p16c781	p16c782
p16f785	p16hv785	p16f818	p16f819	p16cr83	p16f83
p16c84	p16cr84	p16f84	p16f84a	p16f87	p16f870
p16f871	p16f872	p16f873	p16f873a	p16f874	p16f874a
p16f876	p16f876a	p16f877	p16f877a	p16f88	p16f882
p16f883	p16f884	p16f886	p16f887	p16f913	p16f914
p16f916	p16f917	p16c923	p16c924	p16c925	p16c926
p16f946	p17cxx	p17c42	p17c42a	p17cr42	p17c43
p17cr43	p17c44	p17c752	p17c756	p17c756a	p17c762
p17c766	p18cxx	p18f1220	p18f1230	p18f1320	p18f13k22
p18lf13k22	p18f1330	p18f13k50	p18lf13k50	p18f14k22	p18lf14k22
p18f14k50	p18lf14k50	p18f2220	p18f2221	p18f2320	p18f23k20
p18f2321	p18f2331	p18f2410	p18f24j10	p18f24j11	p18lf24j11
p18c242	p18f242	p18f2420	p18f24k20	p18f2423	p18f2431
p18f2439	p18f2450	p18f24j50	p18lf24j50	p18f2455	p18f2458
p18f248	p18f2480	p18f2510	p18f25j10	p18f25j11	p18lf25j11
p18f2515	p18c252	p18f252	p18f2520	p18f25k20	p18f2523
p18f2525	p18f2539	p18f2550	p18f25j50	p18lf25j50	p18f2553
p18f258	p18f2580	p18f2585	p18f2610	p18f26j11	p18lf26j11
p18f2620	p18f26k20	p18f26j50	p18lf26j50	p18f2680	p18f2681
p18f2682	p18f2685	p18f4220	p18f4221	p18f4320	p18f43k20
p18f4321	p18f4331	p18f4410	p18f44j10	p18f44j11	p18lf44j11
p18c442	p18f442	p18f4420	p18f44k20	p18f4423	p18f4431
p18f4439	p18f4450	p18f44j50	p18lf44j50	p18f4455	p18f4458
p18f448	p18f4480	p18f4510	p18f45j10	p18f45j11	p18lf45j11
p18f4515	p18c452	p18f452	p18f4520	p18f45k20	p18f4523
p18f4525	p18f4539	p18f4550	p18f45j50	p18lf45j50	p18f4553
p18f458	p18f4580	p18f4585	p18f4610	p18f46j11	p18lf46j11
p18f4620	p18f46k20	p18f46j50	p18lf46j50	p18f4680	p18f4681
p18f4682	p18f4685	p18c601	p18f6310	p18f63j11	p18f6390
p18f63j90	p18f6393	p18f6410	p18f64j11	p18f64j15	p18f6490
p18f64j90	p18f6493	p18f65j10	p18f65j11	p18f65j15	p18f6520
p18f6525	p18f6527	p18f65j50	p18c658	p18f6585	p18f65j90
p18f66j10	p18f66j11	p18f66j15	p18f66j16	p18f6620	p18f6621
p18f6622	p18f6627	p18f6628	p18f66j50	p18f66j55	p18f66j60
p18f66j65	p18f6680	p18f66j90	p18f67j10	p18f67j11	p18f6720
p18f6722	p18f6723	p18f67j50	p18f67j60	p18f67j90	p18c801
p18f8310	p18f83j11	p18f8390	p18f83j90	p18f8393	p18f8410
p18f84j11	p18f84j15	p18f8490	p18f84j90	p18f8493	p18f85j10
p18f85j11	p18f85j15	p18f8520	p18f8525	p18f8527	p18f85j50
p18c858	p18f8585	p18f85j90	p18f86j10	p18f86j11	p18f86j15
p18f86j16	p18f8620	p18f8621	p18f8622	p18f8627	p18f8628

p18f86j50	p18f86j55	p18f86j60	p18f86j65	p18f8680	p18f86j90
p18f87j10	p18f87j11	p18f8720	p18f8722	p18f8723	p18f87j50
p18f87j60	p18f87j90	p18f96j60	p18f96j65	p18f97j60	ps500
ps810	rf509af	rf509ag	rf675f	rf675h	rf675k
sx18	sx20	sx28	sx48	sx52	

Chapter 2

gpasm

2.1 Running gpasm

The general syntax for running gpasm is

```
gpasm [options] asm-file
```

Where options can be one of:

Option	Meaning
a <format>	Produce hex file in one of four formats: inhx8m, inhx8s, inhx16, inhx32 (the default).
c	Output a relocatable object in the older version of the Microchip COFF format
C	Output a relocatable object in the new Microchip COFF format
d	Output debug messages
D symbol[=value]	Equivalent to “#define <symbol> <value>”
e [ON OFF]	Expand macros in listing file
g	Use debug directives for COFF
h	Display the help message
i	Ignore case in source code. By default gpasm treats “fooYa” and “FOOYA” as being different.
I <directory>	Specify an include directory
l	List the supported processors
L	Ignore nolist directives
m	Memory dump
M	Output a dependency file
n	Use DOS style newlines (CRLF) in hex file. This option is disabled on win32 systems.
o <file>	Alternate name of hex output file
p<processor>	Select target processor
q	Quiet
r <radix>	Set the radix, i.e. the number base that gpasm uses when interpreting numbers.<radix> can be one of “oct”, “dec” and “hex” for bases eight, ten, and sixteen respectively. Default is “hex”.
u	Use absolute paths
v	Print gpasm version information and exit
w [0 1 2]	Set the message level
y	Enable 18xx extended mode

Unless otherwise specified, gpasm removes the “.asm” suffix from its input file, replacing it with “.lst” and “.hex” for the list and hex output files respectively. On most modern operating systems case is significant in filenames. For this reason you should ensure that filenames are named consistently, and that the “.asm” suffix on any source file is in lower case.

gpasm always produces a “.lst” file. If it runs without errors, it also produces a “.hex” file or a “.o” file.

2.1.1 Using gpasm with “make”

On most operating systems, you can build a project using the make utility. To use gpasm with make, you might have a “makefile” like this:

```
tree.hex: tree.asm treedef.inc
    gpasm tree.asm
```

This will rebuild “tree.hex” whenever either of the “tree.asm” or “treedef.inc” files change. A more comprehensive example of using gpasm with makefiles is included as example1 in the gpasm source distribution.

2.1.2 Dealing with errors

gpasm doesn’t specifically create an error file. This can be a problem if you want to keep a record of errors, or if your assembly produces so many errors that they scroll off the screen. To deal with this if your shell is “sh”, “bash” or “ksh”, you can do something like:

```
gpasm tree.asm 2>&1 | tee tree.err
```

This redirects standard error to standard output (“2>&1”), then pipes this output into “tee”, which copies it input to “tree.err”, and then displays it.

2.2 Syntax

2.2.1 File structure

gpasm source files consist of a series of lines. Lines can contain a label (starting in column 1) or an operation (starting in any column after 1), both, or neither. Comments follow a “;” character, and are treated as a newline. Labels may be any series of the letters A-z, digits 0-9, and the underscore (“_”); they may not begin with a digit. Labels may be followed by a colon (“:”).

An operation is a single identifier (the same rules as for a label above) followed by a space, and a comma-separated list of parameters. For example, the following are all legal source lines:

```

                                ; Blank line
loop    sleep                    ; Label and operation
        incf    6,1              ; Operation with 2 parameters
        goto    loop            ; Operation with 1 parameter
```

2.2.2 Expressions

gpasm supports a full set of operators, based on the C operator set. The operators in the following table are arranged in groups of equal precedence, but the groups are arranged in order of increasing precedence. When gpasm encounters operators of equal precedence, it always evaluates from left to right.

Operator	Description
=	assignment
	logical or
&&	logical and
&	bitwise and
	bitwise or
^	bitwise exclusive-or
<	less than
>	greater than
==	equals
!=	not equals
>=	greater than or equal
<=	less than or equal
<<	left shift
>>	right shift
+	addition
-	subtraction
*	multiplication
/	division
%	modulo
UPPER	upper byte
HIGH	high byte
LOW	low byte
-	negation
!	logical not
~	bitwise no

Any symbol appearing in column 1 may be assigned a value using the assignment operator (=) in the previous table. Additionally, any value previously assigned may be modified using one of the operators in the table below. Each of these operators evaluates the current value of the symbol and then assigns a new value based on the operator.

Operator	Description
=	assignment
++	increment by 1
--	decrement by 1
+=	increment
-=	decrement
*=	multiply
/=	divide
%=	modulo
<<=	left shift
>>=	right shift
&=	bitwise and
=	bitwise or
^=	bitwise exclusive-or

2.2.3 Numbers

gpasm gives you several ways of specifying numbers. You can use a syntax that uses an initial character to indicate the number's base. The following table summarizes the alternatives. Note the C-style option for specifying hexadecimal numbers.

base	general syntax	21 decimal written as
binary	B'[01]*'	B'10101'
octal	O'[0-7]*'	O'25'
decimal	D'[0-9]*'	D'21'
hex	H'[0-F]*'	H'15'
hex	0x[0-F]*	0x15

When you write a number without a specifying prefix such as "45", gpasm uses the current radix (base) to interpret the number. You can change this radix with the RADIX directive, or with the "-r" option on gpasm's command-line. The default radix is hexadecimal.

If you do not start hexadecimal numbers with a digit, gpasm will attempt to interpret what you've written as an identifier. For example, instead of writing C2, write either 0C2, 0xC2 or H'C2'.

Case is not significant when interpreting numbers: 0ca, 0CA, h'CA' and H'ca' are all equivalent.

Several legacy mpasm number formats are also supported. These formats have various shortcomings, but are still supported. The table below summarizes them.

base	general syntax	21 decimal written as
binary	[01]*b	10101b
octal	q'[0-7]*'	q'25'
octal	[0-7]*o	25o
octal	[0-7]*q	25q
decimal	0-9]*d	21d
decimal	.[0-9]*	.21
hex	[0-F]*h	15h

You can write the ASCII code for a character X using 'X', or A'X'.

2.2.4 Preprocessor

A line such as:

```
include foo.inc
```

will make gpasm fetch source lines from the file “foo.inc” until the end of the file, and then return to the original source file at the line following the include.

Lines beginning with a “#” are preprocessor directives, and are treated differently by gpasm. They may contain a “#define”, or a “#undefine” directive.

Once gpasm has processed a line such as:

```
#define X Y
```

every subsequent occurrence of X is replaced with Y, until the end of file or a line

```
#undefine X
```

appears.

The preprocessor will replace an occurrence of #v(expression) in a symbol with the value of “expression” in decimal. In the following expression:

```
number equ 5
label_#v( (number +1) * 5 )_suffix equ 0x10
```

gpasm will place the symbol “label_30_suffix” with a value of 0x10 in the symbol table.

The preprocessor in gpasm is only *like* the C preprocessor; its syntax is rather different from that of the C preprocessor. gpasm uses a simple internal preprocessor to implement “include”, “#define” and “#undefine”.

2.2.5 Processor header files

gputils distributes the Microchip processor header files. These files contain processor specific data that is helpful in developing PIC applications. The location of these files is reported in the gpasm help message. Use the INCLUDE directive to utilize the appropriate file in your source code. Only the name of the file is required. gpasm will search the default path automatically.

2.3 Directives

2.3.1 Code generation

In absolute mode, use the ORG directive to set the PIC memory location where gpasm will start assembling code. If you don't specify an address with ORG, gpasm assumes 0x0000. In relocatable mode, use the CODE directive.

2.3.2 Configuration

You can choose the fuse settings for your PIC implementation using the __CONFIG directive, so that the hex file set the fuses explicitly. Naturally you should make sure that these settings match your PIC hardware design.

The __MAXRAM and __BADRAM directives specify which RAM locations are legal. These directives are mostly used in processor-specific configuration files.

2.3.3 Conditional assembly

The IF, IFNDEF, IFDEF, ELSE and ENDIF directives enable you to assemble certain sections of code only if a condition is met. In themselves, they do not cause gpasm to emit any PIC code. The example in section 2.3.4 for demonstrates conditional assembly.

2.3.4 Macros

gpasm supports a simple macro scheme; you can define and use macros like this:

```
any    macro parm
        movlw parm
        endm
...
any    33
```

A more useful example of some macros in use is:

```
; Shift reg left
slf    macro    reg
        clrc
        rlf    reg,f
endm

; Scale W by "factor". Result in "reg", W unchanged.
scale  macro    reg, factor
        if (factor == 1)
            movwf reg                ; 1 X is easy
        else
            scale  reg, (factor / 2) ; W * (factor / 2)
            slf    reg,f                ; double reg
```

```

        if ((factor & 1) == 1)    ; if lo-bit set ..
            addwf  reg,f          ; .. add W to reg
        endif
    endif
endm

```

This recursive macro generates code to multiply W by a constant “factor”, and stores the result in “reg”. So writing:

```
scale    tmp,D'10'
```

is the same as writing:

```

movwf   tmp        ; tmp = W
clrc
rlf     tmp,f      ; tmp = 2 * W
clrc
rlf     tmp,f      ; tmp = 4 * W
addwf   tmp,f      ; tmp = (4 * W) + W = 5 * W
clrc
rlf     tmp,f      ; tmp = 10 * W

```

2.3.5 \$

$\$$ expands to the address of the instruction currently being assembled. If it’s used in a context other than an instruction, such as a conditional, it expands to the address the next instruction would occupy, since the assembler’s idea of current address is incremented after an instruction is assembled. $\$$ may be manipulated just like any other number:

```

$
$ + 1
$ - 2

```

and can be used as a shortcut for writing loops without labels.

```

LOOP:  BTFSS flag,0x00
        GOTO LOOP

        BTFSS flag,0x00
        GOTO $ - 1

```

2.3.6 Suggestions for structuring your code

Nested IF operations can quickly become confusing. Indentation is one way of making code clearer. Another way is to add braces on IF, ELSE and ENDIF, like this:

```

    IF (this) ; {
        ...
    ELSE      ; }{
        ...
    ENDIF    ; }

```

After you've done this, you can use your text editor's show-matching-brace to check matching parts of the IF structure. In vi this command is "%", in emacs it's M-C-f and M-C-b.

2.3.7 Directive summary

__BADRAM

```
__BADRAM <expression> [, <expression>]*
```

Instructs gpasm that it should generate an error if there is any use of the given RAM locations. Specify a range of addresses with <lo>-<hi>. See any processor-specific header file for an example.

See also: `__MAXRAM`

__BADROM

```
__BADROM <expression> [, <expression>]*
```

Instructs gpasm that it should generate an error if there is any use of the given ROM locations. Specify a range of addresses with <lo>-<hi>. See any processor-specific header file for an example.

See also: `__MAXROM`

__CONFIG

```
__CONFIG <expression>
```

Sets the PIC processor's configuration fuses.

See also: `CONFIG`, `__FUSES`

__FUSES

```
__FUSES <expression>
```

Alias for `__CONFIG`. Sets the PIC processor's configuration fuses.

See also: `CONFIG`

__IDLOCS

```
__IDLOCS <expression> or __IDLOCS <expression1>, <expression2>
```

Sets the PIC processor's identification locations. For 12 and 14 bit processors, the four id locations are set to the hexadecimal value of expression. For 18cxx devices idlocation expression1 is set to the hexadecimal value of expression2.

__MAXRAM

```
__MAXRAM <expression>
```

Instructs gpasm that an attempt to use any RAM location above the one specified should be treated as an error. See any processor specific header file for an example.

See also: `__BADRAM`

__MAXROM

```
__MAXROM <expression>
```

Instructs gpasm that an attempt to use any ROM location above the one specified should be treated as an error. See any processor specific header file for an example.

See also: `__BADROM`

BANKISEL

```
BANKISEL <label>
```

This directive generates bank selecting code for indirect access of the address specified by `<label>`. The directive is not available for all devices. It is only available for 14 bit and 16 bit devices. For 14 bit devices, the bank selecting code will set/clear the IRP bit of the STATUS register. It will use `MOVLB` or `MOVLR` in 16 bit devices.

See also: `BANKSEL`, `PAGESEL`

BANKSEL

```
BANKSEL <label>
```

This directive generates bank selecting code to set the bank to the bank containing `<label>`. The bank selecting code will set/clear bits in the FSR for 12 bit devices. It will set/clear bits in the STATUS register for 14 bit devices. It will use `MOVLB` or `MOVLR` in 16 bit devices. `MOVLB` will be used for enhanced 16 bit devices.

See also: `BANKISEL`, `PAGESEL`

CONFIG

```
CONFIG <expression>[, <expression>]*
```

Sets configuration fuses on 16-bit PIC devices.

See also: `__CONFIG`

CBLOCK

```
CBLOCK [<expression>]
    <label>[:<increment>][,<label>[:<increment>]]
ENDC
```

Marks the beginning of a block of constants <label>. gpasm allocates values for symbols in the block starting at the value <expression> given to CBLOCK. An optional <increment> value leaves space after the <label> before the next <label>.

See also: EQU

CODE

```
<label> CODE <expression>
```

Only for relocatable mode. Creates a new machine code section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.code” will be used. <expression> is optional and specifies the absolute address of the section.

See also: IDATA, UDATA, CODE_PACK

CODE_PACK

```
<label> CODE_PACK <expression>
```

Only for relocatable mode. Creates a new byte-packed machine code section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.code” will be used. <expression> is optional and specifies the absolute address of the section.

See also: IDATA, UDATA, CODE

CONSTANT

```
CONSTANT <label>=<expression> [, <label>=<expression>]*
```

Permanently assigns the value obtained by evaluating <expression> to the symbol <label>. Similar to SET and VARIABLE, except it can not be changed once assigned.

See also: EQU, SET, VARIABLE

DA

```
<label> DA <expression> [, <expression>]*
```

Stores Strings in program memory. The data is stored as one 14 bit word representing two 7 bit ASCII characters.

See also: DT

DATA

```
DATA <expression> [, <expression>]*
```

Generates the specified data.

See also: DA, DB, DE, DW

DB

```
<label> DB <expression> [, <expression>]*
```

Declare data of one byte. The values are packed two per word.

See also: DA, DATA, DE, DW

DE

```
<label> DE <expression> [, <expression>]*
```

Define EEPROM data. Each character in a string is stored in a separate word.

See also: DA, DATA, DB, DW

DT

```
DT <expression> [, <expression>]*
```

Generates the specified data as bytes in a sequence of RETLW instructions.

See also: DATA

DW

```
<label> DW <expression> [, <expression>]*
```

Declare data of one word.

See also: DA, DATA, DB, DW

ELSE

```
ELSE
```

Marks the alternate section of a conditional assembly block.

See also: IF, IFDEF, IFNDEF, ELSE, ENDIF

END

```
END
```

Marks the end of the source file.

ENDC

```
ENDC
```

Marks the end of a CBLOCK.

See also: CBLOCK

ENDIF

ENDIF

Ends a conditional assembly block.

See also: IFDEF, IFNDEF, ELSE, ENDIF

ENDM

ENDM

Ends a macro definition.

See also: MACRO

ENDW

ENDW

Ends a while loop.

See also: WHILE

EQU

<label> EQU <expression>

Permanently assigns the value obtained by evaluating <expression> to the symbol <label>. Similar to SET and VARIABLE, except it can not be changed once assigned.

See also: CONSTANT, SET

ERROR

ERROR <string>

Issues an error message.

See also: MESSG

ERRORLEVEL

ERRORLEVEL {0 | 1 | 2 | +<msgnum> | -<msgnum>}[, ...]

Sets the types of messages that are printed.

Setting	Affect
0	Messages, warnings and errors printed.
1	Warnings and error printed.
2	Errors printed.
-<msgnum>	Inhibits the printing of message <msgnum>.
+<msgnum>	Enables the printing of message <msgnum>.

See also: LIST

EXTERN

```
EXTERN <symbol> [ , <symbol> ]*
```

Only for relocatable mode. Declare a new symbol that is defined in another object file.

See also: GLOBAL

EXITM

```
EXITM
```

Immediately return from macro expansion during assembly.

See also: ENDM

EXPAND

```
EXPAND
```

Expand the macro in the listing file.

See also: ENDM

FILL

```
<label> FILL <expression>,<count>
```

Generates <count> occurrences of the program word or byte <expression>. If expression is enclosed by parentheses, expression is a line of assembly.

See also: DATA DW ORG

GLOBAL

```
GLOBAL <symbol> [ , <symbol> ]*
```

Only for relocatable mode. Declare a symbol as global.

See also: GLOBAL

IDATA

```
<label> IDATA <expression>
```

Only for relocatable mode. Creates a new initialized data section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.idata” will be used. <expression> is optional and specifies the absolute address of the section. Data memory is allocated and the initialization data is placed in ROM. The user must provide the code to load the data into memory.

See also: CODE, UDATA

IF

```
IF <expression>
```

Begin a conditional assembly block. If the value obtained by evaluating <expression> is true (i.e. non-zero), code up to the following ELSE or ENDIF is assembled. If the value is false (i.e. zero), code is not assembled until the corresponding ELSE or ENDIF.

See also: IFDEF, IFNDEF, ELSE, ENDIF

IFDEF

```
IFDEF <symbol>
```

Begin a conditional assembly block. If <symbol> appears in the symbol table, gpasm assembles the following code.

See also: IF, IFNDEF, ELSE, ENDIF

IFNDEF

```
IFNDEF <symbol>
```

Begin a conditional assembly block. If <symbol> does not appear in the symbol table, gpasm assembles the following code.

See also: IF, IFNDEF, ELSE, ENDIF

LIST

```
LIST <expression> [ , <expression> ] *
```

Enables output to the list (“.lst”) file. All arguments are interpreted as decimal regardless of the current radix setting. “list n=0” may be used to prevent page breaks in the code section of the list file. Other options are listed in the table below:

option	description
b=nnn	Sets the tab spaces
f=<format>	Set the hex file format. Can be inhx8m, inhx8s, inhx16, or inhx32.
m=<expression>	Set the maximum ROM address.
mm=[ON OFF]	Memory Map on or off
n=nnn	Sets the number of lines per page
p = <symbol>	Sets the current processor
pe = <symbol>	Sets the current processor and enables the 18xx extended mode
r= [oct dec hex]	Sets the radix
st = [ON OFF]	Symbol table dump on or off
w=[0 1 2]	Sets the message level.

See also: NOLIST, RADIX, PROCESSOR

LOCAL

```
LOCAL <symbol>[[=<expression>], [<symbol>[=<expression>]]*]
```

Declares <symbol> as local to the macro that's currently being defined. This means that further occurrences of <symbol> in the macro definition refer to a local variable, with scope and lifetime limited to the execution of the macro.

See also: MACRO, ENDM

MACRO

```
<label> MACRO [ <symbol> [ , <symbol> ]* ]
```

Declares a macro with name <label>. gpasm replaces any occurrences of <symbol> in the macro definition with the parameters given at macro invocation.

See also: LOCAL, ENDM

MESSG

```
MESSG <string>
```

Writes <string> to the list file, and to the standard error output.

See also: ERROR

NOEXPAND

```
NOEXPAND
```

Turn off macro expansion in the list file.

See also: EXPAND

NOLIST

```
NOLIST
```

Disables list file output.

See also: LIST

ORG

```
ORG <expression>
```

Sets the location at which instructions will be placed. If the source file does not specify an address with ORG, gpasm assumes an ORG of zero.

PAGE

```
PAGE
```

Causes the list file to advance to the next page.

See also: LIST

PAGESEL

```
PAGESEL <label>
```

This directive will generate page selecting code to set the page bits to the page containing the designated <label>. The page selecting code will set/clear bits in the STATUS for 12 bit and 14 bit devices. For 16 bit devices, it will generate MOVLW and MOVWF to modify PCLATH. The directive is ignored for enhanced 16 bit devices.

See also: BANKISEL, BANKSEL, PAGESELW

PAGESELW

```
PAGESELW <label>
```

This directive will generate page selecting code to set the page bits to the page containing the designated <label>. The page selecting code will generate MOVLW and MOVWF to modify PCLATH. The directive is ignored for enhanced 16 bit devices.

See also: BANKISEL, BANKSEL, PAGESEL

PROCESSOR

```
PROCESSOR <symbol>
```

Selects the target processor. See section ?? for more details.

See also: LIST

RADIX

```
RADIX <symbol>
```

Selects the default radix from “oct” for octal, “dec” for decimal or “hex” for hexadecimal. gpasm uses this radix to interpret numbers that don’t have an explicit radix.

See also: LIST

RES

```
RES <mem_units>
```

Causes the memory location pointer to be advanced <mem_units>. Can be used to reserve data storage.

See also: FILL, ORG

SET

```
<label> SET <expression>
```

Temporarily assigns the value obtained by evaluating <expression> to the symbol <label>.

See also: SET

SPACE

SPACE <expression>

Inserts <expression> number of blank lines into the listing file.

See also: LIST

SUBTITLE

SUBTITLE <string>

This directive establishes a second program header line for use as a subtitle in the listing output. <string> is an ASCII string enclosed by double quotes, no longer than 60 characters.

See also: TITLE

TITLE

TITLE <string>

This directive establishes a program header line for use as a title in the listing output. <string> is an ASCII string enclosed by double quotes, no longer than 60 characters.

See also: SUBTITLE

UDATA

<label> UDATA <expression>

Only for relocatable mode. Creates a new uninitialized data section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.udata” will be used. <expression> is optional and specifies the absolute address of the section.

See also: CODE, IDATA, UDATA_ACS, UDATA_OVR, UDATA_SHR

UDATA_ACS

<label> UDATA_ACS <expression>

Only for relocatable mode. Creates a new uninitialized accessbank data section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.udata_acs” will be used. <expression> is optional and specifies the absolute address of the section.

See also: CODE, IDATA, UDATA

UDATA_OVR

<label> UDATA_OVR <expression>

Only for relocatable mode. Creates a new uninitialized overlaid data section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.udata_ovr” will be used. <expression> is optional and specifies the absolute address of the section.

See also: CODE, IDATA, UDATA

UDATA_SHR

```
<label> UDATA_SHR <expression>
```

Only for relocatable mode. Creates a new uninitialized sharebank data section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.udata_shr” will be used. <expression> is optional and specifies the absolute address of the section.

See also: CODE, IDATA, UDATA

VARIABLE

```
VARIABLE <label>[=<expression>, <label>[=<expression>]]*
```

Declares variable with the name <label>. The value of <label> may later be reassigned. The value of <label> does not have to be assigned at declaration.

See also: CONSTANT

WHILE

```
WHILE <expression>
```

Performs loop while <expression> is true.

See also: ENDW

2.3.8 High level extensions

gpasm supports several directives for use with high level languages. These directives are easily identified because they start with “.”. They are only available in relocatable mode.

These features are advanced and require knowledge of how gputils relocatable objects work. These features are intended to be used by compilers. Nothing prevents them from being used with assembly.

.DEF

```
.DEF <symbol> [, <expression> ]*
```

Create a new COFF <symbol>. Options are listed in the table below:

option	description
absolute	Absolute symbol keyword
class=nnn	Sets the symbol class (byte sized)
debug	Debug symbol keyword
extern	External symbol keyword
global	Global symbol keyword
size=nnn	Reserve words or bytes for the symbol
static	Static Symbol keyword
type=nnn	Sets the symbol type (short sized)
value=nnn	Sets the symbol value

This directive gives the user good control of the symbol table. This control is necessary, but if used incorrectly it can have many undesirable consequences. It can easily cause errors during linking or invalid machine code. The user must fully understand the operation of gputils COFF symbol table before modifying its contents.

For best results, only one of the single keywords should be used. The keyword should follow the symbol name. The keyword should then be followed by any expressions that directly set the values. Here is an example:

```
.def global_clock, global, type = T_ULONG, size = 4
See also: .DIM
```

.DIM

```
.DIM <symbol>, <number>, <expression> [, <expression> ] *
```

Create <number> auxiliary symbols, attached to <symbol>. Fill the auxiliary symbols with the values specified in <expression>. The expressions must result in byte sized values when evaluated or be strings. The symbol must be a COFF symbol.

This directive will generate an error if the symbol already has auxiliary symbols. This prevents the user from corrupting automatically generated symbols.

Each auxiliary symbol is 18 bytes. So the contents specified by the expressions must be less than or equal to 18 * <number>.

gpasm does not use auxiliary symbols. So the contents have no effect on its operation. However, the contents may be used by gplink or a third party tool.

See also: .DEF

.DIRECT

```
.DIRECT <command>, <string>
```

Provides a mechanism for direct communication from the program to the debugging environment. This method has no impact on the executable. The symbols will appear in both the COFF files and the COD files.

Each directive creates a new COFF symbol “.direct”. An auxiliary symbol is attached that contains <command> and <string>. The string must be less than 256 bytes. The command must have a value 0 to 255. There are no restrictions on the content, however these messages must conform to the debugging environment. The typical values are summarized in the table below:

ASCII command	description
a	User defined assert
A	Assembler/Compiler defined assert
e	User defined emulator commands
E	Assembler/Compiler defined emulator commands
f	User defined printf
F	Assembler/Compiler defined printf
l	User defined log command
L	Assembler/Compiler/Code verification generated log command

The symbols also contain the address where the message was inserted into the assembly. The symbols, with the final relocated addresses, are available in executable COFF. The symbols are also written to the COD file. They can be viewed using `gpvc`.

See also: `.DEF`, `.DIM`

.EOF

`.EOF`

This directive causes an end of file symbol to be placed in the symbol table. Normally this symbol is automatically generated. This directive allows the user to manually generate the symbol. The directive is only processed if the “-g” command line option is used. When that option is used, the automatic symbol generation is disabled.

See also: `.EOF`, `.FILE`, `.LINE`

.FILE

`.FILE <string>`

This directive causes a file symbol to be placed in the symbol table. Normally this symbol is automatically generated. This directive allows the user to manually generate the symbol. The directive is only processed if the “-g” command line option is used. When that option is used, the automatic symbol generation is disabled.

See also: `.EOF`, `.FILE`, `.LINE`

.IDENT

`.IDENT <string>`

Creates an `.ident` COFF symbol and appends an auxiliary symbol. The auxiliary symbol points to an entry in the string table. The entry contains `<string>`. It is an ASCII comment of any length. This symbol has no impact on the operation of `gputils`. It is commonly used to store compiler versions.

See also: `.DEF`, `.DIM`

.LINE

`.LINE <expression>`

This directive causes and COFF line number to be generated. Normally they are automatically generated. This directive allows the user to manually generate the line numbers. The directive is only processed if the “-g” command line option is used. When that option is used, the automatic symbol generation is disabled. The `<expression>` is always evaluated as decimal regardless of the current radix setting.

See also: `.EOF`, `.FILE`, `.LINE`

.TYPE

```
.TYPE <symbol>, <expression>
```

This directive modifies the COFF type of an existing <symbol>. The symbol must be defined. The type must be 0 to 0xffff. Common types are defined in `coff.inc`.

COFF symbol types default to NULL in `gpasm`. Although the type has no impact linking or generating an executable, it does help in the debug environment.

See also: `.DEF`

2.4 Instructions

2.4.1 Instruction set summary

12 bit Devices (PIC12C5XX)

Syntax	Description
ADDLW <imm8>	Add immediate to W
ADDWF <f>,<dst>	Add W to <f>, result in <dst>
ANDLW <imm8>	And W and literal, result in W
ANDWF <f>,<dst>	And W and <f>, result in <dst>
BCF <f>,<bit>	Clear <bit> of <f>
BSF <f>,<bit>	Set <bit> of <f>
BTFSC <f>,<bit>	Skip next instruction if <bit> of <f> is clear
BTFSS <f>,<bit>	Skip next instruction if <bit> of <f> is set
CALL <addr>	Call subroutine
CLRF <f>,<dst>	Write zero to <dst>
CLRW	Write zero to W
CLRWDT	Reset watchdog timer
COMF <f>,<dst>	Complement <f>, result in <dst>
DECF <f>,<dst>	Decrement <f>, result in <dst>
DECFSZ <f>,<dst>	Decrement <f>, result in <dst>, skip if zero
GOTO <addr>	Go to <addr>
INCF <f>,<dst>	Increment <f>, result in <dst>
INCFSZ <f>,<dst>	Increment <f>, result in <dst>, skip if zero
IORLW <imm8>	Or W and immediate
IORWF <f>,<dst>	Or W and <f>, result in <dst>
MOVF <f>,<dst>	Move <f> to <dst>
MOVLW <imm8>	Move literal to W
MOVWF <f>	Move W to <f>
NOP	No operation
OPTION	
RETLW <imm8>	Load W with immediate and return
RLF <f>,<dst>	Rotate <f> left, result in <dst>
RRF <f>,<dst>	Rotate <f> right, result in <dst>
SLEEP	Enter sleep mode
SUBWF <f>,<dst>	Subtract W from <f>, result in <dst>
SWAPF <f>,<dst>	Swap nibbles of <f>, result in <dst>
TRIS	
XORLW	Xor W and immediate
XORWF	Xor W and <f>, result in <dst>

14 Bit Devices (PIC16CXX)

Syntax	Description
ADDLW <imm8>	Add immediate to W
ADDWF <f>,<dst>	Add W to <f>, result in <dst>
ANDLW <imm8>	And immediate to W
ANDWF <f>,<dst>	And W and <f>, result in <dst>
BCF <f>,<bit>	Clear <bit> of <f>
BSF <f>,<bit>	Set <bit> of <f>
BTFSC <f>,<bit>	Skip next instruction if <bit> of <f> is clear
BTFSS <f>,<bit>	Skip next instruction if <bit> of <f> is set
CALL <addr>	Call subroutine
CLRF <f>,<dst>	Write zero to <dst>
CLRW	Write zero to W
CLRWDT	Reset watchdog timer
COMF <f>,<dst>	Complement <f>, result in <dst>
DECF <f>,<dst>	Decrement <f>, result in <dst>
DECFSZ <f>,<dst>	Decrement <f>, result in <dst>, skip if zero
GOTO <addr>	Go to <addr>
INCF <f>,<dst>	Increment <f>, result in <dst>
INCFSZ <f>,<dst>	Increment <f>, result in <dst>, skip if zero
IORLW <imm8>	Or W and immediate
IORWF <f>,<dst>	Or W and <f>, result in <dst>
MOVF <f>,<dst>	Move <f> to <dst>
MOVLW <imm8>	Move literal to W
MOVWF <f>	Move W to <f>
NOP	No operation
OPTION	
RETFIE	Return from interrupt
RETLW <imm8>	Load W with immediate and return
RETURN	Return from subroutine
RLF <f>,<dst>	Rotate <f> left, result in <dst>
RRF <f>,<dst>	Rotate <f> right, result in <dst>
SLEEP	Enter sleep mode
SUBLW	Subtract W from literal
SUBWF <f>,<dst>	Subtract W from <f>, result in <dst>
SWAPF <f>,<dst>	Swap nibbles of <f>, result in <dst>
TRIS	
XORLW	Xor W and immediate
XORWF	Xor W and <f>, result in <dst>

Ubicom Processors

For Ubicom (Scenix) processors, the assembler supports the following instructions, in addition to those listed under “12 Bit Devices” above.

Syntax	Description
BANK <imm3>	
IREAD	
MODE <imm4>	
MOVMW	
MOVWM	
PAGE <imm3>	
RETI	
RETIW	
RETP	
RETURN	

Special macros

There are also a number of standard additional macros. These macros are:

Syntax	Description
ADD CF <f>,<dst>	Add carry to <f>, result in <dst>
B <addr>	Branch
BC <addr>	Branch on carry
BZ <addr>	Branch on zero
BNC <addr>	Branch on no carry
BNZ <addr>	Branch on not zero
CLRC	Clear carry
CLRZ	Clear zero
SETC	Set carry
SETZ	Set zero
MOVFW <f>	Move file to W
NEGF <f>	Negate <f>
SKPC	Skip on carry
SKPZ	Skip on zero
SKPNC	Skip on no carry
SKPNZ	Skip on not zero
SUBCF <f>,<dst>	Subtract carry from <f>, result in <dst>
TSTF <f>	Test <f>

2.5 Errors/Warnings/Messages

gpasm writes every error message to two locations:

- the standard error output
- the list file (“.lst”)

The format of error messages is:

```
Error <src-file> <line> : <code> <description>
```

where:

<src-file> is the source file where gpasm encountered the error

<line> is the line number

<code> is the 3-digit code for the error, given in the list below

<description> is a short description of the error. In some cases this contains further information about the error.

Error messages are suitable for parsing by emacs' "compilation mode". This chapter lists the error messages that gpasm produces.

2.5.1 Errors

101 ERROR directive

A user-generated error. See the ERROR directive for more details.

108 Illegal character

gpasm encountered an illegal character in a source file.

113 Symbol not previously defined

gpasm encountered an unrecognized symbol.

114 Divide by zero

gpasm encountered a divide by zero.

115 Duplicate Label

Duplicate label or redefining a symbol that can not be redefined.

116 Address label duplicated or different in second pass

Label resolved to a different address on gpasm's second pass.

118 Overwriting previous address contents

gpasm was instructed to write different values into the same address.

120 Call or jump not allowed

gpasm was instructed to write different values into the same address.

121 Illegal label

gpasm encountered an illegal label.

123 Illegal directive

The specified directive is not valid for this processor.

124 Illegal Argument

gpasm encountered an illegal argument in an expression.

125 Illegal Condition

An illegal condition like a missing ENDIF or ENDW has been encountered.

126 Argument out of Range

The expression has an argument that was out of range.

127 Too many arguments

gpasm encountered an expression with too many arguments.

128 Missing argument(s)

gpasm encountered an expression with at least one missing argument.

129 Expected

Expected a certain type of argument.

130 Processor type previously defined

The processor is being redefined.

131 Undefined processor

The processor type has not been defined.

132 Unknown processor

The selected processor is not valid. Check the processors listed in section ??.

133 Hex file format INHX32 required

An address above 32K was specified.

135 Macro name missing

A macro was defined without a name.

136 Duplicate macro name

A macro name was duplicated.

140 Illegal WHILE loop

gpasm encountered an infinite loop or a loop with too many iterations (more than 256).

145 Unmatched ENDM

ENDM found without a macro definition.

149 Object-only directive

Attempt to use relocatable-mode directive when generating HEX file directly.

151 Unresolvable or too complex label

Labels must be resolvable to a relocatable address plus a constant.

152 Wrong section

Code or data defined in an invalid section.

154 Section names must be unique

Multiple object sections were defined with the same name.

156 Operand must be label

gpasm encountered a non-label operand where an address label was expected.

157 ORG at odd address

ORG directive must take an even address as the start of an absolute section.

159 Odd number of FILL bytes

In PIC18CXX devices the number of bytes must be even.

164 Multiple __IDLOC directives

Multiple __IDLOC object sections were defined.

168 Missing brackets

Square brackets required around offset operand.

176 Unknown CONFIG

An error occurred with the CONFIG directive.

177 Cannot mix CONFIG and __CONFIG directives

CONFIG and __CONFIG directives cannot both be used in the same project.

2.5.2 Warnings

201 Symbol not previously defined.

The symbol being #undefined was not previously defined.

202 Argument out of range

The argument does not fit in the allocated space.

203 Opcode in column 1

Opcodes should be indented to distinguish them from labels.

205 Directive in column 1

Directives should be indented to distinguish them from labels.

206 Macro call in column 1

Macro calls should be indented to distinguish them from labels.

207 Label after column 1

Labels should be unindented to distinguish them from directives and opcodes.

209 Missing quote

Inserted close quote after quoted string.

211 Extraneous arguments

Extra arguments were found on the line.

215 Processor superseded by command line

The processor was specified on the command line and in the source file. The command line has precedence.

216 Radix superseded by command line

The radix was specified on the command line and in the source file. The command line has precedence.

217 Hex format superseded by command line

The hex file format was specified on the command line and in the source file. The command line has precedence.

218 Expected DEC, OCT, HEX. Will use HEX.

gpasm encountered an invalid radix.

219 Invalid RAM location specified.

gpasm encountered an invalid RAM location as specified by the `__MAXRAM` and `__BADRAM` directives.

220 Exceeded maximum ROM

Data emitted past maximum ROM address.

222 Error messages can not be disabled

Error messages can not be disabled using the `ERRORLEVEL` directive.

223 Redefining processor

The processor is being reselected by the `LIST` or `PROCESSOR` directive.

224 Use of this instruction is not recommended

Use of the `TRIS` and `OPTION` instructions is not recommended for a PIC16CXX device.

228 Invalid ROM location specified.

gpasm encountered an invalid ROM location as specified by the `__MAXROM` and `__BADROM` directives.

2.5.3 Messages

301 User Message

User message, invoked with the `MESSG` directive.

302 Register not in bank 0

Accessing a register outside of bank 0. User must select the appropriate bank with `banksel` or similar directives.

303 Program word too large. Truncated to core size.

gpasm has encounter a program word larger than the core size of the selected device.

304 ID Locations value too large. Last four hex digits used.

The ID locations value specified is too large.

305 Using default destination of 1 (file).

No destination was specified so the default location was used.

306 Crossing page boundary

ROM address crossed boundary between pages. User must select appropriate page with `pagesel` or similar directives when using `call` or `goto` directives.

308 Warning level superseded by command line

The warning level was specified on the command line and in the source file. The command line has precedence.

309 Macro expansion superseded by command line

Macro expansion was specified on the command line and in the source file. The command line has precedence.

312 Page or Bank selection not needed

This device does not use special page or bank selection code.

313 Uninitialized CBLOCK

First CBLOCK has no initial value. Assuming a value of 0.

316 W register modified

Hidden use of the W register overwrites previous value. User may need to save and restore the original value.

318 Special mnemonic used

Using special instruction mnemonic which may map to one or several instructions.

Chapter 3

gplink

gplink relocates and links gaspm COFF objects and generates an absolute executable COFF.

3.1 Running gplink

The general syntax for running gplink is

```
gplink [options] [objects] [libraries]
```

Where options can be one of:

Option	Meaning
a	Produce hex file in one of four formats: inhx8m, inhx8s, inhx16, inhx32 (the default)
c	Output an executable object
d	Display debug messages
f <value>	Fill unused unprotected program memory with <value>
h	Show the help message
I <directory>	Specify an include directory
l	Disable the list file output
m	Output a map file
o <file>	Alternate name of hex output file
O <level>	Optimization level
q	Quiet
r	Attempt to relocate unshared data sections to shared memory if relocation fails
s <file>	Specify linker script
-t <value>	Create a stack section
v	Print gplink version information and exit
w	Disable processor mismatch warning.

3.2 gplink outputs

gplink creates an absolute executable COFF. From this COFF a hex file and cod file are created. The executable COFF is only written when the “-c” option is added. This file is useful for simulating the design with mpsim. The cod file is used for simulating with gpsim.

gplink can also create a map file. The map file reports the final addresses gplink has assigned to the COFF sections. This is the same data that can be viewed in the executable COFF with gpvo.

3.3 Linker scripts

gplink requires a linker script. This script tells gplink what memory is available in the target processor. A set of Microchip generated scripts are installed with gputils. These scripts were intended as a starting point, but for many applications they will work as is.

If the user does not specify a linker script, gplink will attempt to use the default script for the processor reported in the object file. The default location of the scripts is reported in the gplink help message.

3.4 Stacks

gplink can create a stack section at link time using a stack directive in the linker script. The same feature can be utilized with a -t option on the command line. gplink will create the section and two symbols. `_stack` points to the beginning of the stack section and `_stack_end` points to the end.

3.5 Optimization

gplink is an optimizing linker. There are four different optimization levels. Each level includes all optimizations of lower levels. Increasing the level typically increases the link time required.

3.5.1 Level 0

No optimizations.

3.5.2 Level 1 (default)

Weak Symbols

A weak symbol is an external symbol declaration that isn't used. These symbols are typically created by declaring functions or data that isn't used. Including these symbols might lead to extra objects being extracted from archives for symbol resolution. That will increase the data and program memory used. This optimization removes all weak symbols when the object file is read by the linker.

3.5.3 Level 2

Dead Sections

A dead section is any section that doesn't have relocations pointing to its symbols. This means the code or data in the section is never accessed. This optimization removes the section and its symbols to reduce

program and data memory. This optimization will not remove any absolute sections.

3.5.4 Level 3

No optimizations.

Chapter 4

gplib

gplib creates, modifies and extracts COFF archives. This allows a related group of objects to be combined into one file. Then this one file is passed to gplink.

4.1 Running gplib

The general syntax for running gplib is

```
gplib [options] library [member]
```

Where options can be one of:

Option	Meaning
c	Create a new library
d	Delete member from library
h	Show the help message
n	Don't add the symbol index
q	Quiet mode
r	Add or replace member from library
s	List global symbols in library
t	List member in library
v	Print gplib version information and exit
x	Extract member from library

4.2 Creating an archive

The most common operation is to create a new archive:

```
gplib -c math.a mult.o add.o sub.o
```

This command will create a new archive “math.a” that contains “mult.o add.o sub.o”.

The name of the archive “math.a” is arbitrary. The tools do not use the file extension to determine file type. It could just as easily been “math.lib” or “math”.

When you use the library, simply add it to the list of object passed to `gplink`. `gplink` will scan the library and only extract the archive members that are required to resolve external references. So the application won't necessarily contain the code of all the archive members.

4.3 Other `gplib` operations

Most of the other are useful , but will be used much less often. For example you can replace individual archive members, but most people elect to delete the old archive and create a new one.

4.4 Archive format

The file format is a standard COFF archive. A header is added to each member and the unmodified object is copied into the archive.

Being a standard archive they do include a symbol index. It provides a simple way to determine which member should be extract to resolve external references. This index is not included in `mplib` archives. So using `gplib` archives with Microchip Tools will probably cause problems unless the “-n” option is added when the archive is created.

Chapter 5

Utilities

5.1 gpdasm

gpdasm is a disassembler for gputils. It converts hex files generated by gpasm and gplink into disassembled instructions.

5.1.1 Running gpdasm

The general syntax for running gpdasm is

```
gpdasm [options] hex-file
```

Where options can be one of:

Option	Meaning
c	Decode special mnemonics
h	Display the help message
i	Display hex file information
l	List supported processors
m	Memory dump hex file
p<processor>	Select processor
s	Print short form output
v	Print gpdasm version information and exit
y	Enable 18xx extended mode

gpdasm doesn't specifically create an output file. It dumps its output to the screen. This helps to reduce the risk that a good source file will be unintentionally overwritten. If you want to create an output file and your shell is "sh", "bash" or "ksh", you can do something like:

```
gpdasm test.hex > test.dis
```

This redirects standard output to the file "test.dis".

5.1.2 Comments on Disassembling

- The `gpdasm` only uses a hex file as an input. Because of this it has no way to distinguish between instructions and data in program memory.
- If `gpdasm` encounters an unknown instruction it uses the `DW` directive and treats it as raw data.
- There are DON'T CARE bits in the instruction words. Normally, this isn't a problem. It could be, however, if a file with data in the program memory space is disassembled and then reassembled. Example: `gpdasm` will treat `0x0060` in a 14 bit device as a `NOP`. If the output is then reassembled, `gpasm` will assign a `0x0000` value. The value has changed and both tools are behaving correctly.

5.2 `gpstrip`

`gpstrip` manipulates the sections and symbol tables of `gputils` object files.

5.2.1 Running `gpstrip`

The general syntax for running `gpstrip` is

```
gpstrip [options] object-file
```

Where options can be one of:

Option	Meaning
<code>g</code>	Strip debug symbols
<code>h</code>	Show the help message
<code>k</code>	Keep symbol
<code>n</code>	Remove symbol
<code>o</code>	Alternate output file
<code>p</code>	Preserve dates
<code>r</code>	Remove section
<code>s</code>	Remove all symbols
<code>u</code>	Remove all symbols not needed for relocations
<code>v</code>	Show version
<code>V</code>	Verbose mode
<code>x</code>	Remove non-global symbols

5.3 `gpvc`

`gpvc` is cod file viewer for `gputils`. It provides an easy way to view the contents of the cod files generated by `gpasm` and `gplink`.

5.3.1 Running gpvc

The general syntax for running gpvc is

```
gpvc [options] cod-file
```

Where options can be one of:

Option	Meaning
a	Display all information
d	Display directory header
s	Display symbols
h	Show the help message.
r	Display ROM
l	Display source listing
m	Display debug message area
v	Print gpvc version information and exit

gpvc doesn't specifically create an output file. It dumps its output to the screen. If you want to create an output file and your shell is "sh", "bash" or "ksh", you can do something like:

```
gpvc test.cod > test.dump
```

This redirects standard output to the file "test.dump".

5.4 gpvo

gpvo is COFF object file viewer for gputils. It provides an easy way to view the contents of objects generated by gpasm and gplink.

5.4.1 Running gpvo

The general syntax for running gpvo is

```
gpvo [options] object-file
```

Where options can be one of:

Option	Meaning
b	Binary data
c	Decode special mnemonics
f	File header
h	Show the help message
n	Suppress filenames
s	Section data
t	Symbol data
v	Print gpvo version information and exit
x FILE	Export symbols to an include file.
y	Enable 18xx extended mode

gpvo doesn't specifically create an output file. It dumps its output to the screen. If you want to create an output file and your shell is "sh", "bash" or "ksh", you can do something like:

```
gpvo test.obj > test.dump
```

This redirects standard output to the file "test.dump".

Index

.DEF, 25
.DIM, 26
.DIRECT, 26
.EOF, 27
.FILE, 27
.IDENT, 27
.LINE, 27
.TYPE, 28
__BADRAM, 15
__BADROM, 15
__CONFIG, 15
__FUSES, 15
__IDLOCS, 15
__MAXRAM, 16
__MAXROM, 16

Archive format, 42
ASCII, 12

BANKISEL, 16
BANKSEL, 16
bash, 9, 43, 45, 46

case, 8
CBLOCK, 16
character, 12
CODE, 17
CODE_PACK, 17
comments, 9
CONSTANT, 17
Creating an archive, 41

DA, 17
DATA, 17
DB, 18
DE, 18
DT, 18
DW, 18

ELSE, 18
END, 18
ENDC, 18
ENDIF, 19
ENDM, 19
ENDW, 19
EQU, 19
ERROR, 19
error file, 9
ERRORLEVEL, 19
EXITM, 20
EXTERN, 20

FILL, 20

GLOBAL, 20
GNU, 3
gpasm options, 7
gpdasm, 43
gpvc, 44
gpvo, 44, 45

hex file, 8

IDATA, 20
IF, 21
IFDEF, 21
IFNDEF, 21
include, 12

ksh, 9, 43, 45, 46

labels, 9
License, 3
LIST, 21
LOCAL, 22

MACRO, 22
make, 8

MESSG, 22

NO WARRANTY, 3

NOEXPAND, 22

NOLIST, 22

operators, 9

ORG, 22

Other gplib operations, 42

PAGE, 22

PAGESEL, 23

PAGESELW, 23

PROCESSOR, 23

RADIX, 23

radix, 8, 11

RES, 23

Running gpdasm, 43

Running gplib, 41

Running gplink, 38

Running gpvc, 45

Running gpvo, 44, 45

SET, 23

sh, 9, 43, 45, 46

SPACE, 24

SUBTITLE, 24

tee, 9

TITLE, 24

UDATA, 24

UDATA ACS, 24

UDATA OVR, 24

UDATA SHR, 25

VARIABLE, 25

WHILE, 25